

Spare parts fitting instructions

Part	Lower front frame bush kit
Tools Required	2 x 10mm spanners, small screwdriver
Contents	6 x frame bushes, 2 x caps, bolt, nut and washers

1. Unfold the buggy, remove the front wheel and lay the buggy on its side.

2. Remove the caps over the front frame joint with a small screw driver.

3. Remove the 4 x lower bag holder screws and remove the lower bag holder from the buggy. *Note the bolt locations and washer placement.*

4. Undo the front frame joint with 2 x 10mm spanners and remove the bolt.

5. Because the frame is welded together, you may need to flex the frame arms apart to remove the centre shaft. Noting how the frame components go together, remove the old components and discard.

6. Carefully replace the parts into the frame joint noting they are different and can only go one way. Slide the bolt through and loosely attaché the washer and nut.

7. Before tightening the frame bolt, attach the lower bag holder and tighten the screws. Do not over tighten the nut, just so the frame joint is solid and tight.

8. Push the caps back onto the bolt and nut heads.

