

Spare parts fitting instructions

| | |
|----------------|----------------------------------|
| Part | Lower rear frame bush kit |
| Tools required | 10mm spanners, small screwdriver |
| Contents | 4 x frame bushes, 2 x caps |



1. Unfold the buggy
2. Remove the caps over the rear frame joints with a small screw driver.
3. Undo the top frame joint with 2 x 10mm spanners and remove the bolt.
4. Remove the old components and discard.
5. Carefully replace the parts into the frame joint noting they are different and can only go one way.
6. Push the bolt through the frame joint ensuring the correct washers are in place and tighten the nut. Do not over tighten the nut, just so the frame joint is solid and tight.
7. Push the caps back onto the bolt and nut heads.

