

Spare parts fitting instructions

Part	Rear upper frame bush kit
Tools required	10mm spanners, small screwdriver
Contents	4x frame bushes, 2 x caps, bolt, nut and washer

1. Unfold the buggy
2. Remove the caps over the rear upper frame joint with a small screw driver.
3. Undo the rear upper joint with 2 x 10mm spanners and remove the bolt.
4. Noting how the frame components go together, remove the old components and discard. *Be careful as the frame will be flimsy once the bolt is removed*
5. Carefully replace the parts into the frame joint noting they are different and can only go one way.
6. Push the bolt through the frame joint ensuring the correct washers are in place and tighten the nut. Do not over tighten the nut, just so the frame joint is solid and tight.
7. Push the caps back onto the bolt and nut heads.

