

Spare parts fitting instructions

Part	Speed control
Tools required	Phillips head screwdriver, 8mm spanner, small flat blade screwdriver
Contents	Speed control pot, roller and ends



1. Unfold the buggy
2. Remove the two screws through the handle attaching the frame to the handle. An 8mm spanner may be needed underneath the handle to help undo the bolts.
3. Using a Phillips head screwdriver remove the 6 x screws underneath the handle assembly.
4. The handle assembly should easily fall apart once the screws are removed. *Be careful to no let the wiring get caught, stretched or jammed in the handle.*
5. Disconnect the speed control plug, and remove the speed control pot, roller and ends.
7. Plug in the new speed control pot, roller and ends ensuring the ends are attached as per the old parts. Firmly push down on the end pieces to ensure they fit into the slots well
8. Assemble the handle pieces together carefully noting the wire location and fitment. *Be careful to no let the wiring get caught, stretched or jammed in the handle.*
9. Install the screws and handle bolts in reverse order as above ensuring not to over tighten the screws and bolts.

